

**日本語****ロケーションフリーベースステーションの設定について**

ロケーションフリーベースステーション(LF-B1)のシステムソフトウェアバージョン3.000より、下記の部分が仕様変更になっています。

**機器登録**

ロケーションフリーベースステーションに登録できる機器の台数について  
(取扱説明書<sup>☞</sup>44ページ)

Ver. 3.000より前のシステムソフトウェア	Ver. 3.000以降のシステムソフトウェア
機器は4台まで登録できます。	機器は8台まで登録できます。

登録できる機器の詳細や登録方法については、取扱説明書をご覧ください。

登録パスワードの発行について(取扱説明書<sup>☞</sup>44ページ)

Ver. 3.000より前のシステムソフトウェア	Ver. 3.000以降のシステムソフトウェア
1. [機器登録の受付]で[有効にする]を選ぶ。 2. [セット]をクリックする。 3. 左フレームで[機器登録]をクリックする。 登録パスワードが表示されます。	1. [機器登録の受付]で[有効にする]を選ぶ。 2. [セット]をクリックする。 登録パスワードが表示されます。

ロケーションフリーベースステーションのシステムソフトウェアのバージョンは、ベースステーション設定画面から確認できます。詳細は取扱説明書の「現在の状態を確認する」(<sup>☞</sup>39ページ)をご覧ください。



## About Settings of the LocationFree Base Station

The following is from system software version 3.000 of the LocationFree Base Station (LF-B1) to the specification change.

### Device Registration

#### About the number of devices that can be registered in LocationFree Base Station (Operating Instructions [④ 41 page](#))

System software before from Ver. 3.000	System software since Ver. 3.000
Up to four devices can be registered.	Up to eight devices can be registered.

For details of the device registration and the type of devices that can be registered, refer to the Operating Instructions.

### Generating a Registration Password

(Operating Instructions [④ 42 page](#))

System software before from Ver. 3.000	System software since Ver. 3.000
<ol style="list-style-type: none"><li>1. Select [Enable] under [Register Devices].</li><li>2. Click [Set].</li><li>3. Click [Device Registration] in the left frame. The registration password appears.</li></ol>	<ol style="list-style-type: none"><li>1. Select [Enable] under [Register Devices].</li><li>2. Click [Set]. The registration password appears.</li></ol>

Version Information of system software of LocationFree Base Station can be confirmed from the [Base Station Settings] screen. For details, refer to “Checking the Current Base Station Status” of the Operating Instructions ([④ 36 page](#)).